

aquatica®

Function, Form & Fashion





Baby Boomer™
Corner Walk-In Bathtub

Installation & Care Manual
USA / Canada

Baby Boomer™

Corner Walk-In Bathtub




PARTS LIST




★ Use "1 1/2" PVC or ABS Female Adapter (use of PVC or ABS depends on your local or state plumbing codes) Hub x FIPT

The ABS or PVC female adapter features a hub x female NPT thread connection and provides a means for adapting a solvent weld connection to a threaded connection.


 MEASUREMENTS: inches




Aquatica®
Freestanding
Bath Installer™
(not supplied)




★ Home Depot PART
1 1/2" ABS
Female Adapter
Hub x FIPT





★ 1 1/2" flanged brass
tube for Aquatica®
cable-drive and
concealed bath
wastes.

PLEASE NOTE: Parts marked with  are supplied as part of Aquatica® Freestanding Bath Installer™ Kit (NOT included with bathtub)



P-Trap (not supplied)




TYPICAL FREESTANDING BATHTUB INSTALLATION PROCEDURE

Before you start:


- Ensure that the floor is even.
- The waste-overflow fitting is supplied with the product, however other accessories like the slip joint and adaptors are not included and must be purchased separately.
- Because of the technical features of the product, it should be used only with the supplied waste-overflow or specific 3rd party models that have been tested and approved by us.
- Place the bathtub by raising it up 4" with 4x4 pieces of lumber so you can have access from the bottom of the bathtub.
- The bath must rest on its feet, not the monobloc sides. The feet must be adjusted to compensate for any floor imperfections and leave minimal gap with floor.

INSTALLATION SEQUENCE

- The Aquatica™ bathtub is equipped with factory pre-installed overflow system.
- The waste pipe/p-trap connection must be made directly to the waste/drain outlet located at the bottom of the tub.



- Picture 1-2: the bathtub is leveled via a water level at the intended local installation area.
- Picture 3: place the bathtub by raising it up 4" with 4x4 pieces of lumber so you can have access from the bottom of the bathtub. Important note: *during the installation, the bathtub should not be turned on its side to prevent its weight from deflecting its monobloc sides. This is why it is important to use supports to raise the bathtub above the floor. This will also provide you with easy access to the internal plumbing parts.*




Baby Boomer™

Corner Walk-In Bathtub

INSTALLATION

WARNING

Electrical appliances (plug, switches, lamps, etc.) must be placed or installed at the minimum safety distance of 2' and a height of 7'-6".



Baby Boomer™

Corner/Walk-In Bathtub
INSTALLATION continued

aquatica®
Function, Form & Fashion


1



Take the tub out of the packaging taking care to hold it from the bottom edge of the tub. Lie it near the place where it will be installed.

2

Remove the panel by unscrewing the three retaining screws at the base and sliding it downwards.



3



If not already prepared install the faucet on the bathtub. See the instructions in the faucet box.

aquatica®
Function, Form & Fashion



Baby Boomer™

Corner Walk-In Bathtub

INSTALLATION continued

4

If not already prepared, assembly the drain and distribution column following the instructions in the box. Connect the distribution to the diverter of the taps



The bathtub stands on 6 adjustable feet. The leveling must be carefully adjusted for the correct functioning of the tub.

WARNING

An incorrect execution of these adjustments may cause a not perfect sealing of the door.

First feet 2 and 5 are raised from the ground. Operate on feet number 1,3,4 and 6 to adjust the level.

6

The tub is set by the factory with a height at the top edge of 3'-1 4/5".

At this stage it is not important if the tub does not stand perfectly on the ground, the adjustment will be done later.



Baby Boomer™

Corner/Walk-In Bathtub

INSTALLATION continued

aquatica®
Function, Form & Fashion



7

Place the tub in the installation corner and level it perfectly using the feet 1,3,4 and 6.

CAUTION To level the tub, act only on the feet and not on the threaded rods. It is important that all levelling feet are completely touching the floor and that the level is perfect for the door system to work properly.

8


Once the optimal positioning is achieved, stop the feet by acting on the nut of each foot. Now adjust the feet 2 and 5 to touch the floor, without forcing. Stop the feet by acting on their nut.

WARNING

The feet 2 and 5 must not lift any of the previously adjusted feet otherwise it should compromise the stability of the tub and above all the door system would not work properly.



9



Connect the drain of the tub to the ground predisposition as indicated on the technical details.

Connect the taps to the wall arrangement as indicated on the technical details.

aquatica®
Function, Form & Fashion


Baby Boomer™

Corner Walk-In Bathtub

INSTALLATION continued

10

All tubs are individually 100% water tested at the factory in order to ensure their perfect functioning. During this phase of the installation it is necessary to test the product in order to verify that all the adjustments made at the factory have been maintained. Due to improper transport or assembly, in some cases there may be leaks.




In case of leaks, in the lower part or along the edge near the closing handle, only with a perfect installation as previously described, it will be possible to act on the tub shape by opening or closing the front side. For this aim, on the front frame, there is a column with an adjustment on the head formed by a plate with threaded rod screwed to the tub and two nuts, one placed on the front and one on the back. This system is able to slightly change the closure.

A) Leak at the base: it will be necessary to screw the rear nut to the column, bringing it against the plate mounted on the tub. Screw the outer nut half a turn at a time until the leak is resolved. Screw the rear nut to the column again. With this operation we have opened the front side

B) Leak on the high side: it will be necessary to unscrew the front column nut half a turn at a time and do the same on the rear nut until the leak is resolved. With this operation we closed the front side

WARNING The adjustments must be minimal in order to avoid creating contrary sealing problems.

At the end of each adjustment, the two nuts must always be tightened to the column.




Baby Boomer™

Corner Walk-In Bathtub

INSTALLATION continued

aquatica®
Function, Form & Fashion

13



Insert the panel under the tub again, starting from the front side, then under the door and then under the short side.

14



To stop the panel, insert it under the edge of the tub, between the edge itself and the thrust springs. Use the supplied wedges to help you.

Replace the previously removed screws at the base of the panel.

Remove the wedges used as a riser.

aquatica®
Function, Form & Fashion

Baby Boomer™

Corner Walk-In Bathtub

Certification



FEATURES




- 18 Gauge Epoxy coated Metal Deck Flange
- Designed to be installed in an 8" joist space
- Can be installed with Waterproofing Membrane (*bronte™ NobleSeal TS Recommended)
- CSA Certified for Canadian and US markets

KIT INCLUDES


- 2 Brass Tailpieces (Fine Thread and Flanged)
- Freestanding Bath Installer™ assembly with 1-1/2" DWV ABS tailpiece
- Cutting template

INSTALLATION TIPS


- Use 5" hole saw to cut sub floor (not included). Cutting template included
- Do not cut the brass Tailpiece as this may cause a leak
- Secure Deck Flange with 6 screws (not included)




Fine Thread Tailpiece
Attaches to 314 Series
Direct/Offset Bath Wastes
and Integral Bath Wastes.



Flanged Tailpiece
Attaches to 314DC Series
Cable-Drive® Bath Wastes
and Integral Bath Wastes.



ABS or PVC Adapter Kit
Attaches to ABS or PVC Bath
Wastes and includes Brass
Nut and Poly Washer.




Baby Boomer™

Corner/Walk-In Bathtub


INSTALLATION INSTRUCTIONS

aquatica®
Function, Form & Fashion


Attaches to Freestanding Bath W/O



- 1
- A. Cut 5" hole into wood sub-floor (use supplied Cutout Template).
- B. Measure and cut ABS Tailpiece as necessary to ensure a secure connection to P-Trap below.
- C. Insert Freestanding Bath Installer™ assembly into floor opening and connect to Pipe below.
- D. Affix to sub-floor with 6 screws (not supplied)



- 2
- A. Install flooring surface, leaving a 5" opening to access Drain.
- B. Affix the appropriate brass Tailpiece to the Waste & Overflow. **NOTE: DO NOT CUT THE BRASS TAILPIECE AS THIS MAY CAUSE A LEAK.** Ensure the measurement between the base of the Drain and P-Trap will accommodate the Tailpiece. Other lengths available (contact Aquatica).



- 3
- A. Cut out the Installation Label with a utility knife and remove to expose the Drain.
- B. Apply lubricant (supplied) to the Tailpiece.
- C. Position the Tub and brass Tailpiece in-line with the Drain.
- D. Carefully lower the tub with the installed brass Tailpiece into the Red Collar in Drain assembly. Ensure Tailpiece is fully engaged with Seal.

IMPORTANT: Do not remove Installation Label until Step 3.

DO NOT CUT THE SUPPLIED BRASS TAILPIECE. Doing so may cause a leak.

Disassembling the drain or cutting the Tailpiece will void the warranty.

aquatica®
Function, Form & Fashion


True Ofuro - Maintenance Instructions

True Ofuro - Инструкция по уходу

True Ofuro - Installation & Entretien

True Ofuro - Manuale per il corretto mantenimento

True Ofuro - Instrucciones para la correcta manutención



Maintenance Instructions

The smooth surface of your Aquatica® Acrylic Bathtub accumulates hardly any dirt, and can be maintained by simply cleaning with a soft cloth, using a mild detergent in water, then wiping over with a dry cloth.

Avoid using abrasive cleansers or solvents, which will cause damage to the surface. Damage caused by use of these products, or any other inappropriate treatment, is not covered by our guarantee.



Инструкция по уходу

Поверхность легко чистится. За счет гладкости грязь к ней не прилипает. Для регулярного ухода используйте мягкую ткань, мыльный раствор и воду. После чистки вытирайте поверхность сухой тканью, которая хорошо впитывает влагу.

Не используйте губки с абразивной поверхностью и агрессивные растворители, которые могут повредить ванну. Повреждения, возникшие вследствие неправильного ухода, не покрываются гарантией.



Installation & Entretien

Cette surface est facile à entretenir et à nettoyer. Sa surface particulièrement lisse, ne retiens que très peu la saleté. Un entretien quotidien nécessite simplement l'utilisation d'un chiffon doux, de l'eau et un peu de savon. Essuyer avec un chiffon sec. L'utilisation de détergents ou de solvants endommageraient cette surface. Les dommages resultants d'un traitement non conforme effectué par l'utilisateur sont exclus de la garantie que nous offrons.



Manuale per il corretto mantenimento

La superficie necessita di pulizia ed accorgimenti per il corretto mantenimento. Una superficie liscia non accumula lo sporco. Usare una spugnetta con del detergente non aggressivo per una pulizia regolare. Asciugare con un panno. Evitare l'uso di solventi o materiali abrasivi: potrebbero rovinare la superficie.

Un danno causato da trattamento inappropriato non verra' coperto dalla garanzia.



Instrucciones para la correcta manutención

La superficie debe de ser limpiada y adecuadamente mantenida. Una superficie lisa no acumula suciedad.

Utilice una esponja con un detergente suave para la limpieza diaria. Seque con un paño.

No utilice disolventes o materiales abrasivos ya que podrían dañar la superficie.

Los daños causados por el tratamiento inadecuado no serán cubiertos por la garantía.

CE

Aquatica Plumbing Europe LTD
Dzirnavu iela 73-2, Riga, Latvia
13
EN 14516
CL1
CA-DA